



Available to Ambient Lights of  
Short sleeve of 3 Series  
Instruction Manual

SHENZHEN HUAYI AUTO PARTS TECHNOLOGY CO.,LTD.



Use a seesaw to open the inner shell of the handle



Remove it



Use the inner screwdriver to remove buckle all screws inside the handle



Use the seesaw to open the of car door



Open all buckles



Grab the shell of the door and lift it up and remove it



Open the wiring harness and plug inside the shell



Use the raft to open the switch panel of the lifter



Unplug the power connector of the lifter



Find the appropriate ambient light. Press the screw on the door (in order to get the location mark of the screw)



Install wires of ambience lights and separate them with small lights



Drill on the mark (in the front)

Available to Ambient Lights of BMW 3 Series  
Instruction Manual



Put the wire of ambient light



Press the ambient light into the drilling hole



Fix all ambience lights with screws



(in the driver place, left rear door and right rear door) the wire of lights can be directly inserted into the switch plug of lifters



Location of light of the driver place  
(in the pedal)



The positive pole is connected to the original red and gray line, and the negative pole is connected to the original brown and blue line.