18 Color Ambient Lighting
Control Description

|	
4	Press 4# button and keep 5 second,breath style on. Press it again and keep 5 second , breath style off.
5	Driving style.
6	Press 6# button and keep 5 second,skip to next color.
7	Press 7# button and keep 5 second,back to last color.

Dial Control

Dial Code Selection

Dial Code 1	Dial Code 2	
Under	Under	NBT Screen Control
Up	Under	NBT CD Key Control
Under	Up	CIC CD Key Control

2010-2014 CIC system control installation

A/C panel lights

A pillar connector/L

A pillar connector/R

Driver foot light

Copilot foot light

iDrive Transfer
Power-taking mode

B pillar connector/L

B pillar connector/R

Plug into the rotary knob connector

Wires connector

Ambient module

Plug into the rotary knob connector

IDrive power surpport

2010-2014 CIC system car body wires routing construction

Door panel female connector

Plug the plug as the same color

A pillar wire/L

Driver foot light

Copilot foot light

Door panel female connector

Plug the plug as the same color

A pillar wire/R

B pillar wire/L

Plug the plug as the same color

Door panel male connector

B pillar wire/R

Plug the plug as the same color

Door panel male connector